



Engineering Company, Inc.

30 Progress Avenue (203) 888-9900

Seymour, CT 06483 (203) 888-1145



Software Release/Installation Notes

Date: 7/9/2009

Version 8.00.041

Machine / Platform:DRS25

Compatibility

Can be applied to any version that is 8.00.000 or higher.

Installation Requirements

Must have an existing and operational installation before attempting this upgrade.

Important: **This upgrade requires the nozzle calibration to be performed when the current/existing release is below 8.00.016.**

Important: **Versions above 8.00.027-001 implement an optional text-to-speech engine for speaking profile process messages. An additional setup program will be automatically started at the end of the normal installation process.**

Application Folder(s)

C:\Program Files\Air-Vac-Engineering\DRS25

C:\Program Files\Air-Vac-Engineering\DRS25\data

Installation Procedure

Overview

The database must be updated before the application program can be started.

Step 1:

Locate and double-click on v8.n.nn.nnn.exe file to automatically extract/copy the files to the correct target folder location. Files will be copied to the C:\Program Files\Air-Vac-Engineering\DRS25\data folder.

Step 2:

Locate and access the following folder: C:\Program Files\Air-Vac-Engineering\DRS25\data

Double-click on the database_update_tool.exe. This program will generate the necessary batch file used to update the drs25 database. The generated name of the batch file is based on the currently installed DRS25 software version. For example, if the current software version is 8.00.017, then the batch file name will be 8.00.017-UpdateDB.bat. Only 1 batch file should be available per software installation/upgrade.

Step 3:

Verify that the #.##.###-UpdateDB.bat file was created in the C:\Program Files\Air-Vac-Engineering\DRS25\data folder.

Step 4:

Double-click on the #.##.###-UpdateDB.bat file. This program will update the database to match the new application program.

Step 5:

This software version offers an option to speak (text-to-speech synthesis) process and control messages at the end of each process event, therefore, an additional setup program will automatically be activated allowing 2 additional voice selections to be available (Microsoft Mike / Microsoft Mary). Please follow the detailed instructions below.

Step 6:

Start the DRS25 software and login. Click on the Options / About menu item and verify the software version.

This completes the installation procedure for this release.

Release Notes - Overview

Existing Software Issues:

1. Button or footswitch activities (click or press) are sluggish and may be missed or get corrupted regarding the currently active state (i.e. enable or disable z-axis motor).

This issue was corrected.